

User manual

Solar Grid-tied Inverter

Product Model: SOFAR 7K~10.5KTLM-G3



Contents

| | |
|--|--------|
| Preface..... | I |
| 1. Basic safety information..... | - 1 - |
| 1.1. Safety instructions..... | - 1 - |
| 1.2. Symbols and signs..... | - 5 - |
| 2. Product characteristics..... | - 7 - |
| 2.1. Product dimensions..... | - 7 - |
| 2.2. Function characteristics..... | - 10 - |
| 2.3. Efficiency curve..... | - 11 - |
| 3. Installation..... | - 12 - |
| 3.1. Installation Process..... | - 12 - |
| 3.2. Checking Before Installation..... | - 12 - |
| 3.3. Tools..... | - 15 - |
| 3.4. Determining the Installation Position..... | - 16 - |
| 3.5. Moving the SOFAR 7K~10.5KTLM-G3..... | - 18 - |
| 3.6. Installing SOFAR 7K~10.5KTLM-G3..... | - 19 - |
| 4. Electrical Connections..... | - 21 - |
| 4.1. Outlines of this chapter..... | - 21 - |
| 4.2. Connecting PGND Cables..... | - 22 - |
| 4.3. Connecting DC Input Power Cables..... | - 24 - |
| 4.4. Connecting AC Output Power Cables..... | - 27 - |
| 4.5. Com port connection..... | - 31 - |
| 4.6. WIFI/GPRS..... | - 38 - |
| 5. Commissioning of inverter..... | - 40 - |
| 5.1. Safety inspection before commissioning..... | - 40 - |
| 5.2. Start inverter..... | - 40 - |
| 5.3. Shutdown inverter..... | - 41 - |
| 5.4. Setting power quality response modes..... | - 41 - |
| 6. Operation interface..... | - 42 - |
| 6.1. Operation and Display Panel..... | - 42 - |
| 6.2. Standard Interface..... | - 43 - |
| 6.3. Main Interface..... | - 45 - |
| 6.4. Update Software online..... | - 53 - |
| 7. Trouble shooting..... | - 55 - |
| 7.1. Trouble shooting..... | - 55 - |
| 7.2. Maintenance..... | - 58 - |
| 8. Technical data..... | - 60 - |
| 8.1. Input parameters (DC)..... | - 60 - |
| 8.2. Output parameters (AC)..... | - 61 - |
| 8.3. Efficiency, Protection and Communication..... | - 62 - |
| 8.4. General Date..... | - 63 - |
| 9. Quality Assurance..... | - 64 - |

Notice

This manual contains important safety instructions that must be followed during installation and maintenance of the equipment.

Save these instructions!

This manual must be considered as an integral part of the equipment. The manual must always accompany the equipment, even when it is transferred to another user or field.

Copyright Declaration

The copyright of this manual belongs to Shenzhen SOFARSOLAR Co.,Ltd. Any corporation or individual should not plagiarize, partially copy or fully copy it (including software, ect .), and no reproduction or distribution of it in any form or by any means. All right reserved.

SOFARSOLAR reserves the right of final interpretation. This manual is subject to change according to user's or customer's feedback. Please check our website at <http://www.sofarsolar.com> for latest version.

The current Version updated at 202203018.

Preface

Outline

Please read the product manual carefully before installation, operation or maintenance. This manual contains important safety instructions and installation instructions that must be followed during installation and maintenance of the equipment.

Scope

This product manual describes the installation, electrical connections, commissioning, maintenance and troubleshooting of SOFAR 7K~10.5KTLM-G3 inverters:

7KTLM-G3

7.7KTLM-G3

8KTLM-G3

9KTLM-G3

10KTLM-G3

10.5KTLM-G3






Keep this manual where it will be accessible at all times.

Target Group

This manual is intended for qualified electrical technical personnel who are responsible for inverter installation and commissioning in the PV power system and PV plant operator.

Symbols Used

This manual provides safety operation information and uses the symbol in order to ensure personal and property security and property security and use inverter efficiently when operating the inverter. You must understand these emphasized information to avoid the personal injury and property loss. Please read the following symbols used in this manual carefully.

| | |
|---|---|
|  Danger | <p>Danger indicates a hazardous situation which, if not avoided, will result in death or serious injury.</p> |
|  Warning | <p>Warning indicates a hazardous situation which, if not avoided, could result in death or serious injury.</p> |
|  Caution | <p>Caution indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.</p> |
|  Attention | <p>Attention indicates potential risks which, if not avoided, may lead to equipment fault or property damage.</p> |
|  Note | <p>Note provides tips that are valuable for the optimal operation of the product.</p> |

1. Basic safety information

**Note**

If you have any question or problem when you read the following information, please contact Shenzhen SOFARSOLAR Co., Ltd.

1.1. Safety instructions

Read and understand the instructions of this manual, and be familiar with relevant safety symbols in this chapter, then start to install and troubleshoot the equipment. According to the national and state requirements, before connecting to the electrical grid, you must get permission from the local electrical grid operation can only be performed by qualified electrical engineer. Please contact the nearest authorized service center if any maintenance or repair is needed. Contact your distributor for the information of the nearest authorized service center. Do NOT repair it by yourself, it may cause injury or property damage. Before installing and maintaining the equipment, you should turn the DC switch OFF to cut off the high voltage DC of the PV array. You can also turn the switch in the PV combiner box OFF to cut off the high voltage DC. Otherwise, serious injury may be caused.


Qualified persons

The customer must make sure the operator has the necessary skill and training to do his/her job. Staff in charge of using and maintaining the equipment must be skilled, aware and mature for the described tasks and must have the reliability to correctly interpret what is described in the manual. For safety reason only a qualified electrician, who has received training and / or has demonstrated skills and knowledge in construction and in operation of this unit, can install this inverter. Shenzhen SOFARSOLAR Co., Ltd does not take any responsibility for

the property destruction and personal injury because of any incorrect use.

Installation requirements

Please install inverter according to the following section. Fix the inverter on an appropriate object with enough load bearing capacity (such as walls, PV racks etc.), and ensure that inverter is vertical placed. Choose a place suitable for installing electrical devices and assure there is enough fire exit space, convenient for maintenance. Maintain proper ventilation to ensure enough air cycle to cool the inverter.







Transport requirements

If you find packing problems that may cause the damage of the inverter, or find any visible damage, please immediately notice the responsible transportation company. You can ask solar equipment installation contractor or Shenzhen SOFARSOLAR Co.Ltd for help if necessary.



Transport of the equipment, especially by road, must be carried out with by suitable ways and means for protecting the components (in particular, the electronic components) from violent shocks, humidity, vibration, etc.

Electric connection



Please comply with all the current electrical regulations about accident prevention in dealing with the solar invert.

| | |
|---|---|
|  | Before the electrical connection, make sure to use opaque material to cover the PV modules or to disconnect PV array DC switch. Exposure to the sun, PV array will produce a dangerous voltage! |
| Danger | |
|  | All installation accomplished only by professional electrical engineer! Must be trained; |
| Warning | Completely read the manual operation and understand relevant matter. |
|  | Get permission from the local electrical grid operator, complete all electrical connections by professional electrical engineer, then connect inverter to electrical grid. |
| Attention | |
|  | It's forbidden to remove the tamper evident label, or open the inverter. Otherwise Sofarsolar will not provide warranty or maintenance! |
| Note | |

Operation


| | |
|---|---|
|  | Touching the electrical grid or the terminal of the equipment may lead to electrocution or fire! Don't touch the terminal or conductor connected to the electrical grid. |
| Danger | Pay attention to any instructions or safety documents related to grid connection. |
|  | Some internal components will be very hot when inverter is working. Please wear protective gloves! Keep it away from kids ! |
| Attention | |

Maintenance and repair




| | |
|---|---|
|  | <p>Before any repair work, turn OFF the AC circuit breaker between the inverter and electrical grid first, then turn OFF the DC switch. After turning OFF the AC circuit breaker and DC switch, wait for 5 minutes at least before carrying out any maintenance or repair work.</p> |
| Danger | |
|  | <p>Inverter should work again after removing any faults. If you need any repair work, please contact with the local authorized service center.</p> |
| Attention | <p>Can't open the internal components of inverter without authorized. Shenzhen SOFARSOLAR Co., Ltd. does not take any responsibility for the losses from that.</p> |

EMC / noise level of inverter

Electromagnetic compatibility (EMC) refers to that one electrical equipment functions in a given electromagnetic environment without any trouble or error, and impose no unacceptable effect upon the environment. Therefore, EMC represents the quality characters of an electrical equipment. The inherent noise-immune character: immunity to internal electrical noise. External noise immunity: immunity to electromagnetic noise of external system. Noise emission level: influence of electromagnetic emission upon environment.







| | |
|--|--|
|  | <p>Electromagnetic radiation from inverter may be harmful to health!</p> |
| Danger | <p>Please do not continue to stay around the inverter in less than 20 cm when inverter is working.</p> |




1.2. Symbols and signs

| | |
|---|--|
|  | Caution of burn injuries due to hot enclosure! You can only touch the screen and pressing key of the inverter while it's working. |
| Caution | |
|  | PV array should be grounded in accordance to the requirements of the local electrical grid operator! We suggest that all PV module frames and inverter are reliably grounded to protect the PV system and personnel security. |
| Attention | |
|  | Ensure input DC voltage < Max. DC voltage .Over voltage may cause permanent damage to inverter or other losses, which will not be included in warranty! |
| Warning | |

Signs on the inverter

There are some symbols which are related to security on the inverter. Please read and understand the content of the symbols, and then start the installation.

| | |
|---|--|
|  | There is a residual voltage in the inverter! Before opening the equipment, operator should wait for five minutes to ensure the capacitor is discharged completely. |
|  | Caution, risk of electric shock. |
|  | Caution hot surface. |
|  | Comply with the Conformance Européenne (CE) certification. |
|  | Grounding point. |
|  | Please read this manual before install SOFAR 7K~10.5KTLM-G3. |

| | |
|---|--|
|  | This indicates the degree of protection of the equipment according to IEC standard 70-1 (EN 60529 June 1997). |
|  | Positive pole and negative pole of the input voltage (DC). |
|  | RCM (Regulatory Compliance Mark) The product complies with the requirements of the applicable Australian standards. |

2. Product characteristics

Outlines of this chapter

Product dimensions

This section introduces the field of use, and the overall dimensions of SOFAR 7K~10.5KTLM-G3 inverters.

Function description

This section introduces how SOFAR 7K~10.5KTLM-G3 inverters work and the function modules inside.


Efficiency curves

This section introduces the efficiency curves of in the inverter.

2.1. Product dimensions

SOFAR 7K~10.5KTLM-G3 is a dual MPPT grid-tied PV inverter which converts the DC power generated by PV arrays into sine wave single-phase AC power and feeds it to the public electrical grid, AC circuit breaker (refer to Section 4.4) and DC switch used as disconnect device, and the disconnect device shall be easily accessible.

Note: The DC switch must comply with AS60947.3



SOFAR 7K~10.5KTLM-G3 inverters can only be used with photovoltaic modules that do not require one of the poles to be grounded. The operating current during normal operation must not exceed the limits specified in the technical specifications. Only the photovoltaic modules can be connected to the input of the inverter (do not connect batteries or other sources of power supply). The choice of optional parts of inverter should be made by a qualified technician who knows the installation conditions clearly.

Overall dimensions: $W \times H \times D = 468\text{mm} \times 380\text{mm} \times 187\text{mm}$

Figure 2-2 Front view and left view dimensions of SOFAR 7K~10.5KTLM-G3






Figure 2-3 Bracket dimensions of SOFAR 7K~10.5KTL-G3



◆ Labels on the equipment



The labels must NOT be hidden with objects and extraneous parts (rags, boxes, equipment, etc.); they must be cleaned regularly and kept visible at all times.



| SOFAR Solar Grid-tied Inverter | |
|---|--------------------------|
| Model No: | SOFAR_8KTLM-G3 |
| Max.DC Input Voltage | 600V |
| Operating Max.DC Voltage Range | 50-550V |
| Max. Input Current | 80A/16A/36A |
| Max. PV Ins. | 8000A/200A |
| Nominal Grid Voltage | 200V/230V |
| Max. Output Current | 40A |
| Nominal Grid Frequency | 50/60Hz |
| Nominal Output Power | 8000W |
| Max. Output Power | 8800W |
| Power Factor | 1 (adjustable 0.8) |
| Ingress Protection | IP20 |
| Operating Temperature Range | -30°C~+45°C |
| Protection Class | Class I |
| Inverter Topology | Non-Isolated |
| Manufacturer: Shenzhen SOFAR SOLAR Co., Ltd. Address: 401, Building 4, AnTingDa Industrial Park, District 86, Xixiang Community, Xixiang Street, Baoan District, Shenzhen, China V080108-11-108A0077 BEC02118-80001237 | |
| | |

2.2. Function characteristics

DC power generated by PV array is filtered through Input Board before entering into Power Board. Input Board also offer functions such as insulation impedance detection and input DC voltage / current detection. DC power is converted to AC power by Power Board. AC power is filtered through Output Board then AC power is fed into the grid. Output Board also offer functions such as grid voltage/output current detection, GFCI and output isolation relay. Control Board provides the auxiliary power, controls the operation state of inverter and shows the operation status by Display Board. Display Board displays fault code when inverter is in abnormal operation conditions. At the same time, Control Board can trigger the relay so as to protect the internal components.

Function module

A. Energy management unit

This control can be used to switch the inverter on/off through an external (remote) control.

B. Feeding reactive power into the grid

The inverter is able to produce reactive power and can therefore feed it into the grid through the setting of the phase shift factor. Feed-in management can be controlled directly by the grid company through a dedicated RS485 serial interface.

C. Limiting the active power fed into the grid

The inverter, if enabled, can limit the amount of active power fed into the grid by the inverter to the desired value (Expressed as a percentage).

D. Self power reduction when grid is over frequency

When the grid frequency is higher than the limited value, inverter will reduce output power which is necessary for the grid stability.

E. Data transmission

The inverter or a group of inverters may be monitored remotely through an advanced communication system based on RS-485 serial interface, or remotely


via the WIFI/GPRS.

F. Software update

Support USB flash drive local upgrade software and WIFI/GPRS remote upgrade software.

Electrical block diagram

Figure2-4 Electrical block diagram



2.3. Efficiency curve







Figure2-5 Efficiency Curve diagram

3. Installation

Outlines of this chapter


This topic describes how to install the SOFAR 7K~10.5KTLM-G3.

Installation notes

| | |
|---|---|
|  Danger | Do NOT install the SOFAR 7K~10.5KTLM-G3 on flammable material. Do NOT install the SOFAR 7K~10.5KTLM-G3 in an area used to store Flammable or explosive material. |
|  Caution | The enclosure and heat sink are very hot while the inverter is working, therefore do NOT install the SOFAR 7K~10.5KTLM-G3 in places where you might touch them inadvertently. |
|  Attention | Consider the weight of SOFAR 7K~10.5KTLM-G3 when transporting and moving the inverters. Choose an appropriate mounting position and surface. Assign at least two persons to install the inverter. |

3.1. Installation Process

Figure 3-1 Installation flowchart



3.2. Checking Before Installation

Checking Outer Packing Materials

Packing materials and components may be damaged during transportation.






Therefore, check the outer packing materials before installing the inverter.









Check the outer packing materials for damage, such as holes and cracks. If any damage is found, do not unpack the SOFAR 7K~10.5KTLM-G3 and contact the dealer as soon as possible. You are advised to remove the packing materials within 24 hours before installing the SOFAR 7K~10.5KTLM-G3 inverter.




Checking Deliverables

After unpacking the inverter, check whether deliverables are intact and complete. If any damage is found or any component is missing, contact the dealer.

Table3-1 Shows the components and mechanical parts that should be delivered.

| NO. | Picture | Description | Quantity |
|-----|---|---|----------|
| 1 |  | 7K~10.5KTLM-G3 | 1pcs |
| 2 |  | Rear panel | 1pcs |
| 3 |  | PV+ input terminal | 3pcs |
| 4 |  | PV- input terminal | 3pcs |
| 5 |  | Metal terminals secured to PV+ input power cables | 3pcs |






| | | | |
|----|---|---|--------------------|
| 6 |  | Metal terminals secured to PV- input power cables | 3pcs |
| 7 |  | COM 16pin Communication Terminal | 1pcs |
| 8 |  | USB acquisition stick (WIFI/GPRS/Ethernet) | 1pcs (Optional) |
| 9 |  | AC Buckler | 1pcs |
| 10 |  | M6 Hexagon screws | 3pcs |
| 11 |  | M4*12 cross screw | 4pcs |
| 12 |  | M6*80 anchoring | 3pcs |
| 13 |  | TO Terminal | 3pcs |










| | | | |
|----|---|-------------------|------|
| 14 |  | Manual | 1pcs |
| 15 |  | The warranty card | 1pcs |
| 16 |  | Registration Form | 1pcs |

3.3. Tools

Prepare tools required for installation and electrical connections.

Table 3-2 Shows the tools required for installation and electrical connections.


| NO. | Tool | Model | Function |
|-----|---|---|--|
| 1 |  | Hammer drill Recommend drill dia. 6mm | Used to drill holes on the wall. |
| 2 |  | Screwdriver | Wiring |
| 3 |  | Cross screwdriver | Remove and install AC terminal screws |
| 4 |  | Removal tool | Remove PV terminal |
| 5 |  | Wire stripper | Strip wire |


| | | | |
|----|---|----------------------|--|
| 6 |  | 5mm Allen Wrench | Turn the screw to connect rear panel with inverter. |
| 7 |  | Crimping tool | Used to crimp power cables |
| 8 |  | Multi-meter | Used to check grounding |
| 9 |  | Marker | Used to mark signs |
| 10 |  | Measuring tape | Used to measure distances |
| 11 |  | Level | Used to ensure that the rear panel is properly installed |
| 12 |  | ESD gloves | Operators wear |
| 13 |  | Safety goggles | Operators wear |
| 14 |  | Anti-dust respirator | Operators wear |

3.4. Determining the Installation Position

Determine an appropriate position for installing the SOFAR 7K~10.5KTLM-G3 inverter. Comply with the following requirements when determining the installation position:

Figure3-2 Installation Requirements





3.5. Moving the SOFAR 7K~10.5KTLM-G3

This topic describes how to move the to the installation position Horizontally SOFAR 7K~10.5KTLM-G3.

Step 1 Open the packaging, insert hands into the slots on both sides of the inverter and hold the handles, as shown in Figure 3-3 and Figure 3-4.

Figure 3-3 Moving the inverter (1)





Figure 3-4 Moving the inverter (2)



Step 2 Lift the SOFAR 7K~10.5KTLM-G3 from the packing case and move it to the installation position.



Attention

To prevent device damage and personal injury, keep balance when moving the inverter because the inverter is heavy.

Do not put the inverter with its wiring terminals contacting the floor because the power ports and signal ports are not designed to support the weight of the inverter. Place the inverter horizontally.

When placing the inverter on the floor, put foam or paper under the inverter to protect its shell.


3.6. Installing SOFAR 7K~10.5KTLM-G3

Step 1 Determine the positions for drilling holes, ensure the hole positions are level, then mark the hole positions using a marker pen, use the hammer drill to drill holes on the wall. Keep the hammer drill perpendicular to the wall, do not shake when drilling, so as not to damage the wall. If the error of the hole positions is too big, you need to reposition.

Step 2 Insert the expansion bolt vertically into the hole, pay attention to the insertion depth of the expanding bolt (should be deep enough).

Step 3 Align the rear panel with hole positions, fix the rear panel on the wall by tightening the expansion bolt with the nuts.


Figure 3-5



Step 4 Hook the inverter to the rear panel. Using an M6 screw to secure the inverter to the rear panel to ensure safety.

Step 5 You can secure the inverter to the rear panel and protect it from theft by installing an anti-theft lock (this action is optional).

Figure 3-6



Attention




The inverter must be installed in a high traffic area where the fault would be seen.

4. Electrical Connections

4.1. Outlines of this chapter

This topic describes the SOFAR 7K~10.5KTLM-G3 inverter electrical connections. Read this part carefully before connecting any cables.

NOTE: Before performing electrical connections, ensure that the DC switch is OFF. Since the stored electrical charge remains in a capacitor after the DC switch is turned OFF, it's necessary to wait for at least 5 minutes for the capacitor to be electrically discharged.

| | |
|---|--|
|  | Installation and maintenance of inverter, must be operated by professional electrical engineer. |
| Attention | |
|  | PV modules generate electric energy when exposed to sunlight and can create an electrical shock hazard. Therefore, before connecting DC input power cable, cover PV modules using opaque cloth |
| Danger | |
|  | For SOFAR 7K~10.5KTLM-G3, open-circuit voltage (V_{OC}) of module arrays connected in series must be $\leq 600V$. |
| Note | |

The connected PV modules must have an IEC 61730 Class A rating

| I _{SC} PV (absolute maximum) | 30A/22.5A/22.5A | |
|--|-------------------|-----|
| Maximum output over current protection | SOFAR 7KTLM-G3 | 37A |
| | SOFAR 7.7KTLM-G3 | 37A |
| | SOFAR 8KTLM-G3 | 42A |
| | SOFAR 9KTLM-G3 | 47A |
| | SOFAR 10KTLM-G3 | 48A |
| | SOFAR 10.5KTLM-G3 | 48A |

The decisive voltage class(DVC)

NOTE:The DVC is the voltage of a circuit which occurs continuously between any two live part in the worst-case rated operating condition when used as intended.

| Interface | DVC |
|---------------------|------|
| PV input interface | DVCC |
| AC output interface | DVCC |
| USB interface | DVCA |
| Com interface | DVCA |

DC switch parameters


| | |
|---|--------------------|
| Rated-insulation voltage | 1500V |
| Rated impulse withstand voltage | 8KV |
| Rated operational current (Ie) | 1100V/30A,600V/55A |
| PV utilization category | DC-21B/PV2 |
| Rated short time withstand current (Icw) | 700A.1S |
| Rated short-circuit making capacity (Icm) | 1.4KA |
| Rated breaking capacity | 1.4KA |

PV terminal parameters

| | |
|---------------------------|-------|
| Rated-insulation voltage | 1000V |
| Rated operational current | 39A |
| Protection class | IP68 |
| Maximum temperature limit | 105°C |

4.2. Connecting PGND Cables

Connect the inverter to the grounding electrode using protection ground (PGND) cables for grounding purpose.

| | |
|---|---|
|  <p>Attention</p> | <p>SOFAR 7K~10.5KTLM-G3 is a transformer-less inverter, this requires the positive pole and negative pole of the PV array are NOT to be grounded. Otherwise, it will cause inverter failure. In the PV power system, all non-current carrying metal parts (such as: PV module frame, PV rack, combiner box enclosure, inverter enclosure) should be connected to earth.</p> |
|---|---|


Prerequisites:

The PGND cables are prepared ($\geq 4\text{mm}^2$ outdoor power cables are recommended for grounding purposes), the color of cable should be yellow-green.

Procedure:

Step 1 Remove the insulation layer with an appropriate length using a wire stripper, as shown in Figure 4-1.


Figure4-1 Preparing a ground cable (1)



Note: L2 is 2 to 3mm longer than L1

Step 2 Insert the exposed core wires into the OT terminal and crimp them by using a crimping tool, as shown in Figure 4-2.

Figure4-2 Preparing a ground cable (2)




Note 1: L3 is the length between the insulation layer of the ground cable and the crimped part. L4 is the distance between the crimped part and core wires protruding from the crimped part.

Note 2: The cavity formed after crimping the conductor crimp strip shall wrap the core wires completely. The core wires shall contact the terminal closely.

Step 3 Install the crimped OT terminal, flat washer using M6 screw, and tighten the screw to a torque of 6 Nm using an Allen wrench.

Figure4-3 Ground terminal composition



1.Tapped hole 2. OT Terminal 3.M6 screw

4.3. Connecting DC Input Power Cables


Table 4-1 Recommended DC input cable specifications

| Cross-Sectional Area (mm ²) | | External Cable Diameter(mm) |
|---|-------------------|-----------------------------|
| Range | Recommended Value | |
| 4.0~6.0 | 4.0 | 4.5~7.8 |

Step 1 Remove cable glands from the positive and negative connectors.

Step 2 Remove the insulation layer with an appropriate length from the positive and negative power cables by using a wire stripper as show in Figure 4-4.

Figure 4-4 Connecting DC input power cables




1.Positive power cable 2. Negative power cable

Note: L2 is 2 to 3 mm longer than L1.

Step 3 Insert the positive and negative power cables into corresponding cable glands.

Step 4 Insert the stripped positive and negative power cables into the positive and negative metal terminals respectively and crimp them using a clamping tool. Ensure that the cables are crimped until they cannot be pulled out by force less than 400 N, as shown in Figure 4-5.

Figure 4-5 Connecting DC input power cables




1.Positive power cable 2. Negative power cable

Step 5 Insert crimped power cables into corresponding housings until you hear a "click" sound. The power cables snap into place.

Step 6 Reinstall cable glands on positive and negative connectors and rotate them against the insulation covers.

Step 7 Insert the positive and negative connectors into corresponding DC input terminals of the inverter until you hear a "click" sound, as shown in Figure 4-6.

Figure 4-6 Connecting DC input power cables



1. Bayonet

Note: Please use the multimeter to confirm the positive and negative poles of the photovoltaic array!

Follow-up Procedure

To remove the positive and negative connectors from the inverter, insert a removal wrench into the bayonet and press the wrench with an appropriate strength, as shown in Figure 4-7.





Figure 4-7 Removing a DC input connector



4.4. Connecting AC Output Power Cables

Connect the SOFAR 7K~10.5KTLM-G3 to the AC power distribution frame or power grid using AC output power cables.



Caution

It is not allowed for several inverters to use the same circuit breaker.
It is not allowed to connect loads between inverter and circuit breaker.
AC breaker used as disconnect device, and the disconnect device shall remain readily operable.

Context

SOFARSOLAR has already integrated RCMU (residual current monitoring unit) inside inverter, If an external RCD is required, a type-A RCD with rated residual current of 100mA or higher is suggested. Please check with the local regulation for the sizing of rated residual current.

All the AC output cables used for the inverters are outdoor three-core cables. To facilitate the installation, use flexible cables. Table 4-2 lists the recommended specifications for the cables.

Figure 4-8 NOT allowed: connect loads between inverter and circuit breaker




Table4-2 Recommended AC output cable specifications

| Model | 7KTLM-G3 | 7.7KTLM-G3 | 8KTLM-G3 | 9KTLM-G3 | 10KTLM-G3 | 10.5KTLM-G3 |
|----------------|--------------------|--------------------|--------------------|---------------------|---------------------|---------------------|
| Cable (Copper) | ≥ 6mm ² | ≥ 6mm ² | ≥ 6mm ² | ≥ 10mm ² | ≥ 10mm ² | ≥ 10mm ² |
| Breaker | 60A | 60A | 60A | 100A | 100A | 100A |

Note: The rated power of the meter must be greater than the maximum power of

the inverter.

Multi core copper wire

AC cable should be correctly sized to ensure the power loss in AC cable is less than 1% of the rated power. If the resistance of the AC cable is too high, it will cause a huge increase in the AC voltage, which may lead to a

disconnection of the inverter from the electrical grid. The relationship between power loss in AC cable and wire length, wire cross sectional area is shown in the following figure:






Figure 4-9 Wire length, wire cross sectional area and wire power loss




The AC output terminal of this product is equipped with high current 3-core terminal block and customized AC output waterproof cover, which meets the IP65 level requirements after installation, and the AC output cable needs to be wired by the customer. The appearance of the AC connector is shown in figure 4-10 below.

Figure 4-10 AC terminal connector picture




Wiring Procedure as following:


Step 1 Select appropriate cables according to Table 4-2, Remove the insulation layer of the AC output cable using a wire stripper according to the figure shown below: A:15-25mm
B:6~8mm




Step 2 Use press pliers to press the TO terminal and the cable. The TO terminal is covered with insulating bushings. The terminals should not be exposed.




Step 3 Disassemble the AC cover as shown below and run the cable through the PG connector and AC cover.



Step 4 Connect the AC output cable according to the following requirements:
Connect the yellow and green wires into the keyhole marked with "PE" and tighten it with an internal cross screwdriver;
Connect the brown wire into the keyhole marked with "L" and tighten it with an internal cross screwdriver;
Connect the blue wire into the keyhole marked with "N" and tighten it with an internal cross screwdriver;



Step 5 Fix the AC waterproof cover on the box body with M4 screw



Caution

Before installing or removing the AC connector, ensure that the power grid is disconnected.

4.5. COM Port Connection

The com port location of the SOFAR 7K~10.5KTLM-G3 is shown in the figure below.

Figure 4-11 COM port appearance





Table 4-3 Com port pin definitions (The terminal type is either of the following)

- 31 -

Copyright © Shenzhen SOFAR SOLAR Co., Ltd

| COM | PIN | Definition | Function | Note |
|---|-----|------------|---|---|
|  | 1 | 485_TX+ | RS485 differential signal + | Wired monitoring or inverter cascade monitoring |
| | 2 | 485_TX+ | RS485 differential signal + | |
| | 3 | 485_TX- | RS485 differential signal - | |
| | 4 | 485_TX- | RS485 differential signal - | |
| | 5 | RS485-A | RS485 differential signal + | Meter communication |
| | 6 | RS485-B | RS485 differential signal - | |
| | 7 | GND | DRMS port logical IO | The logic interface pin definitions and circuit connections are so follows: Logic interface pin are defined according to different standard requirements |
| | 8 | DRM0 | | |
| | 9 | DRM1/5 | | |
| | 10 | DRM2/6 | | |
| | 11 | DRM3/7 | | |
| | 12 | DRM4/8 | | |
| | 13 | N/A | N/A | N/A |
| | 14 | N/A | N/A | N/A |
| | 15 | CT+ | The current sensor outputs a positive electrode | Used to connect current sensor of power grid |
| | 16 | CT- | The current sensor outputs a negative electrode | |

4.4.1 Logic interface

(a) Logic interface for AS/NZS 4777.2:2020, also known as inverter demand response modes (DRMs).

The inverter will detect and initiate a response to all supported demand response commands within 2 s. The inverter will continue to respond while the mode remains asserted.

Table 4-4 Function description of the DRMs terminal

| Pin NO. | Function |
|---------|----------|
| 9 | DRM1/5 |
| 10 | DRM2/6 |
| 11 | DRM3/7 |
| 12 | DRM4/8 |
| 7 | GND |
| 8 | DRM0 |

NOTE: Supported DRM command: DRM0, DRM5, DRM6, DRM7, DRM8.

(b) Logic interface for VDE-AR-N 4105:2018-11, is in order to control and/or limit the inverter's output power.

The inverter can be connected to a RRCR (Radio Ripple Control Receiver) in order to dynamically limit the output power of all the inverters in the installation.

Figure 4-12 Inverter – RRCR Connection




Table 4-5 Function description of the terminal

| Pin NO. | Pin name | Description | Connected to (RRCR) |
|---------|----------|-----------------------|---------------------|
| 9 | L1 | Relay contact 1 input | K1 - Relay 1 output |
| 10 | L2 | Relay contact 2 input | K2 - Relay 2 output |
| 11 | L3 | Relay contact 3 input | K3 - Relay 3 output |
| 12 | L4 | Relay contact 4 input | K4 - Relay 4 output |
| 7 | G | GND | Relays common node |

Table 4-6 The inverter is preconfigured to the following RRCR power levels

Relay status: close is 1, open is 0

| L1 | L2 | L3 | L4 | Active Power | Cos(φ) |
|----|----|----|----|--------------|--------|
| 1 | 0 | 0 | 0 | 0% | 1 |
| 0 | 1 | 0 | 0 | 30% | 1 |
| 0 | 0 | 1 | 0 | 60% | 1 |
| 0 | 0 | 0 | 1 | 100% | 1 |

(c) Logic interface for EN50549-1:2019, is in order to cease active power output within five seconds following an instruction being received at the input interface.

Figure 4-13 Inverter – RRCR Connection




Table 4-7 Function description of the terminal

| Pin NO. | Pin name | Description | Connected to (RRCR) |
|---------|----------|-----------------------|---------------------|
| 9 | L1 | Relay contact 1 input | K1 - Relay 1 output |
| 7 | G | GND | K1 - Relay 1 output |

Table 4-8 The inverter is preconfigured to the following RRCR power levels.

Relay status: close is 1, open is 0

| L1 | Active Power | Power drop rate | Cos(φ) |
|----|--------------|-----------------|--------|
| 1 | 0% | <5 seconds | 1 |
| 0 | 100% | / | 1 |

Step4 Insert the terminal as per the printed label, and then tighten the screws to fix the waterproof cover, rotate the cable gland clockwise to fasten it securely.


4.4.2 RS485 interface

By RS485 interface, transfer the inverter power output information, alarm information, operation state to the PC terminal or local data acquisition device, then uploaded to the server.

If only one SOFAR 7K~10.5KTLM-G3 is used, use a communication cable, refer to section 4.5.2 for COM pin definition, and select RS485 port to connect.

Note: the inverter should not be installed in multiple phase combinations.

Figure 4-14 A single SOFAR 7K~10.5KTLM-G3 connecting communications



4.4.3 CT interface

Generation and Export Limit Control functions for the inverter are available but require the use of an external measurement device to obtain grid information.

There are 2 ways to obtain grid information:

- Plan A: CT (default)
- Plan B: Meter + CT (optional)

Note: CT and Meter is supplied separately to the inverter. Contact manufacturer/importer/distributor to order CT and/or Meter.

To obtain grid information via Plan A:

Connect the wires according to the wiring method as shown in "Figure 4-16 Plan A", and enable Anti-Reflux Power function and set the Reflux Power limit on the menu interface of the machine. Hard Anti-Reflux also needs to be enabled to take effect. Refer to <6.3 Main interface→1 Enter Setting→10.Set Reflux P> in this manual for specific operation methods. If Plan A is selected, Select CT from <6.3 Main Interface →1 Enter Setting→ 13.PCC Select>

To obtain grid information via Plan B:

Wiring according to the wiring method as shown in "Figure 4-16 Plan B", The setting of Anti-Reflux Power function is the same as that of Plan A. The electricity meter function will also need to be enabled via the menu interface of the machine. Refer to <6.3 Main interface→A Enter Setting> in this manual for specific operation methods. If Plan B is selected, Select Meter from <6.3 Main Interface →1 Enter Setting→ 13.PCC Select>

Please Note:

Anti-Reflux Function = Export Limit function

Reflux Power = Export Power


Hard Anti-Reflux control = Hard Export limit control

Anti-Reflux Control = Soft Export limit control


When Anti-Reflux function is enabled, the reflux power of point of common coupling (PCC) will be limited to the set Reflux Power limit. Both Hard Anti-Reflux Control and Anti-Reflux Control can be used together. However, when Hard Anti-Reflux control is enabled, Anti-Reflux power limit cannot exceed the Hard Anti-Reflux power limit. If the Anti-reflux power exceeds the Hard Anti-Reflux power limit, the limit value is reported to trigger the overload protection.

When communication signal with the electricity meter is lost, the output power of the inverter is limited to the value of soft export limit and does not trigger fault protection. When Hard anti reflux control is enabled, a loss of communication with the meter will trigger the inverter into a fault protection state.

Figure 4-16
Plan A:CT (default)



Plan B:Meter+CT (optional)



4.6. WIFI/GPRS




Figure 4-17 Connect one USB acquisition stick (WIFI version) to wireless router





Figure 4-18 Connect multiple USB acquisition stick (WIFI version) to wireless router



NOTE

The length of the RS485 communication cable should be less than 1000 m.

The length of the WIFI communication cable should be less than 100 m.

If multiple SOFAR 7K~10.5KTLM-G3 are connected to the monitoring device over an RS485/USB converter, a maximum of 31 inverters can be connected in a

daisy chain.

The operation information (generated energy, alert, operation status) of the inverter can be transferred to PC or uploaded to the server via WiFi/GPRS. Users can choose to use web or APP for monitoring and viewing according to their needs. They need to register an account and bind the device with the WiFi/GPRS SN number. The SN number of the WiFi/GPRS shall be affixed to the package box and the WiFi/GPRS.

Web: <https://home.solarmanpv.com> (Recommended browser: Chrome58、Firefox49、IE9 and above version) .

APP: Android: Go to Android Market and search “SolarMAN”.


IOS: Go to App Store and search “SolarMAN”.

SolarMAN-3.0-Web User Manual, Please visit the <https://doc.solarmanpv.com/web/#/7>.

SolarMAN-App User Manual, Please visit the <https://doc.solarmanpv.com/web/#/14>.

5. Commissioning of inverter

5.1. Safety inspection before commissioning

| | |
|--|---|
|  Attention | Ensure that DC and AC voltages are within the acceptable range of the inverter. |
|--|---|

5.2. Start inverter

Step 1: Turn ON the DC switch.

Step 2: Turn ON the AC circuit breaker.

When the DC power generated by the solar array is adequate, the SOFAR 7K~10.5KTLM-G3 inverter will start automatically. Screen showing “normal” indicates correct operation.

NOTE: Choose the correct country code. (Refer to section 6.3 of this manual)

Notice: Different distribution network operators in different countries have different requirements regarding grid connections of PV grid connected inverters. Therefore, it's very important to make sure that you have selected the correct country code according to requirements of local authority. Please consult qualified electrical engineer or personnel from electrical safety authorities about this.

Detection methods of isolated islands: Reactive Power Disturbance.

Shenzhen SOFAR SOLAR Co., Ltd. is not responsible for any consequences arising out of incorrect country code selection. If the inverter indicates any fault, please refer to Section 7.1 of this manual —— trouble shooting for help.

NOTE:The inverter can monitor the power grid in real time,The protection can be realized when the power grid is abnormal, so that the inverter is separated from the power grid.

5.3. Shutdown inverter

Step 1: Turn OFF the AC circuit breaker.

Step 2: Turn OFF the DC switch.

5.4. Setting power quality response modes

The setting and viewing method of power quality response mode and power grid protection.

Once the power quality and grid settings have been selected at commissioning, these settings will be locked, and customers cannot modify by themselves. These settings require professional and technical personnel to conduct them by issuing and transmitting instructions on the remote monitoring platform, on the premise that the data acquisition rod is installed (WiFi/GPRS/Ethernet). And the account must be authorized by SOFARSOLAR.

- Power quality settings can be set/view/changed by logging onto solarmanpv.com.
- Access to solarmanpv.com is restricted to authorised personnel only (refer to Section 4.6 for instructions on accessing solarmanpv.com).
- An account must be created to use solarmanpv.com.
- Technical personnel can send control instructions on the monitoring page to modify the mode and parameters of the machine, and the corresponding instructions need to be provided by internal professionals.

6. Operation interface

Outlines of this chapter

This section introduces the display, operation, buttons and LED indicator lights of SOFAR 7K~10.5KTLM-G3 Inverter.

6.1. Operation and Display Panel

Buttons and Indicator lights



Button:

“^” Short press UP button = go up

“^” Long press UP button = exit menu or current interface

“v” Short press DOWN button = go down

“v” Long press DOWN button = enter menu or current interface

Indicator Lights:

RUN (Green)









ON: “ Normal ” state

Flash: “ Wait ” or “ Check ”state

FAULT (Red)

ON: “ Fault ” or “ Permanent ”state


6.2. Standard Interface



When power-on, LCD interface displays INITIALIZING, refer to the picture below.



When control board is successfully connected with communication board, the LCD will display the current state of the inverter as shown in the figure below.



Inverter states includes: wait、check、normal、fault and permanent

Wait: Inverter is waiting to Check State at the end of reconnection time. In this state, grid voltage value is between the max and min limits and so on; If not, Inverter will go to Fault State or Permanent State.

Check: Inverter is checking isolation resistance, relays, and other safety requirements. It also does self-test to ensure inverter software and hardware are functional. Inverter will go to Fault State or Permanent State if any error or fault occurs.

Normal: Inverter enter to Normal State, it is feeding power to the grid; inverter will go to Fault State or Permanent state if any error or fault occurs.

Fault: Fault State: Inverter has encountered recoverable error. It should recover if the errors disappear. If Fault State continues; please check the inverter according error code.

Permanent: Inverter has encountered unrecoverable error; a technician is required to debug the error according to the presented error code.

When the control board and communication board connection fails, the LCD display interface as shown in the figure below.

DSP communicate fail

6.3. Main Interface

Long press the “√” button under standard interface to enter into main interface, including:

| | |
|---------------|-------------------------|
| Normal | -----Long press the “√” |
| | 1.Enter Setting |
| | 2.Event List |
| | 3.SystemInfo |
| | 4.System Time |
| | 5.Software Update |

(A) “Enter Setting” Interface as below:

| | |
|------------------------|-------------------------|
| 1.Enter Setting | -----Long press the “√” |
| 1.Set Time | 9.Set Language |
| 2.Clear Energy | 10.SetAntiReflux |
| 3.Clear Events | 11.LogicInterfac |
| 4.Set Country | 12.IV Curve Scan |
| 5.On-Off Control | 13.PCC Select |
| 6.Set Energy | 14.Autotest Fast |
| 7.Set Address | 15.Autotest STD |
| 8.Set Inputmode | |

Long press the “√” button to Enter the main interface of "1.Enter Setting" and long press the “√” to enter the setting menu. You can switch up and down to choose what you want by short pressing the “^” and “√” .

Note1: Some settings need to enter the password (the default password is 0001) , when entering the password, short press the “^” and “√” to change the number, long press the “√” to confirm the current number, and long press the “√” after entering the correct password. If "password error, try again" appears, you will need to re-enter the correct password.

1. Set Time

Set the system time for the inverter.

2. Clear Energy

Clean the inverter of the total power generation.

3. Clear Events

Clean up the historical events recorded in the inverter.

4. Set Country

Select the country grid parameters, or through the mobile APP. To import a country profile, a USB drive with valid country code is required. inserted then select and import the country profile in the "Set Country" menu.

To use the Bluetooth APP to select the correct country code, the account must be linked and authorised as an installer. Once the country is set, it is read-only and can only be viewed and cannot be modified by the end user.

Please contact and discuss with SOFARSOLAR technical support if you require a non standard parameter set.

Table 6-1 List of regulated countries

| Code | | Country | Code | | Country |
|------|------|-------------------------|------|------|-----------------|
| 000 | 000* | Germany VDE4105 | 024 | 000 | Cyprus |
| | 001 | Germany BDEW | 025 | 000 | India |
| | 002* | Germany VDE0126 | 026 | 000 | Philippines |
| 001 | 000 | Italia CEI-021 Internal | 027 | 000 | New Zealand |
| | 001* | Italia CEI-016 Italia | 028 | 000 | Brazil |
| | 002* | Italia CEI-021 External | | 001 | Brazil LV |
| | 003 | Italia CEI0-21 In Areti | | 002 | Brazil 230 |
| 002 | 000 | Australia-A | 029 | 003 | Brazil 254 |
| | 008 | Australia-B | | 000* | Slovakia VSD |
| | 009 | Australia-C | | 001* | Slovakia SSE |
| 003 | 000 | Spain RD1699 | 033 | 002* | Slovakia ZSD |
| 004 | 000* | Turkey | | 000* | Ukraine |
| 005 | 000 | Denmark | 034 | 000 | Norway |
| | 001 | Denmark TR322 | | 001 | Norway-LV |
| 006 | 000* | Greece Continent | 035 | 000 | Mexico LV |
| | 001* | Greece island | 038 | 000 | Wide-Range-60Hz |
| 007 | 000* | Netherland | 039 | 000* | Ireland EN50438 |
| 008 | 000* | Belgium | 040 | 000 | Thailand PEA |
| 009 | 000 | UK G59/G99 | | 001 | Thailand MEA |
| | 001 | UK G83/G98 | 042 | 000 | LV-Range-50Hz |
| 010 | 000 | China | 044 | 000 | South Africa |
| | 001 | China Taiwan | 046 | 000* | Dubai DEWG |

| | | | | | |
|-----|------|----------------------|-----|------|---------------|
| 011 | 000* | France | | 001 | Dubai DEWG MV |
| | 001 | France FAR Arrete23 | 107 | 000* | Croatia |
| 012 | 000 | Poland | 108 | 000* | Lithuania |
| 013 | 000 | Austria Tor Erzeuger | | | |
| 014 | 000 | Japan | | | |
| 018 | 000 | EU EN50438 | | | |
| | 001* | EU EN50549 | | | |
| 019 | 000 | IEC EN61727 | | | |
| 020 | 000 | Korea | | | |
| 021 | 000 | Sweden | | | |
| 022 | 000 | Europe General | | | |

For The Australian Market:

For compliance with AS/NZS 4777.2:2020 please select from

- 002-000 Australia A (Australia Region A)
- 002-008 Australia B (Australia Region B)
- 002-009 Australia C (Australia Region C)

Please contact your local grid operator for which option to select

Note: By selecting 002-000 Australia A, 002-008 Australia B or 002-009 Australia C the power quality response mode and grid protection settings will be reset to their default values for Australia Region A, B, C respectively.

Default grid settings for different regions are shown in the following table:

| Protective function | Protective function limit | Trip delay time | Maximum disconnection time |
|---------------------|---------------------------|-----------------|----------------------------|
| Undervoltage 2(V<<) | 70V | 1s | 2s |
| Undervoltage 1(V<) | 180V | 10s | 11s |
| Overvoltage 1(V>) | 265V | 1s | 2s |
| Overvoltage 2(V>) | 275V | - | 0.2s |

| | Region | Australia A | Australia B | Australia C | New Zealand |
|------------------------|---------------------------------|-------------|-------------|-------------|-------------|
| Under-frequency 1 (F<) | Protective function limit value | 47Hz | 47Hz | 45Hz | 45Hz |
| | Trip delay time | 1s | 1s | 5s | 1s |
| | Maximum disconnection time | 2s | 2s | 6s | 2s |
| Over- | Protective | 52Hz | 52Hz | 55Hz | 55Hz |

| | | | | | |
|---------------------|----------------------------|------|------|------|------|
| frequency 1 (F>) | function limit value | | | | |
| | Trip delay time | - | - | - | - |
| | Maximum disconnection time | 0.2s | 0.2s | 0.2s | 0.2s |

Default volt-watt settings for different regions are shown in the following table:

| Region | Default value | V_{L2} | V_{L1} | V_{W1} | V_{W2} |
|-------------|--------------------------------------|----------|----------|----------|----------|
| Australia A | Voltage | 207 | 215 | 253 | 260 |
| | Inverter output (P) % of S_{rated} | 20% | 100% | 100% | 20% |
| Australia B | Voltage | 195 | 215 | 250 | 260 |
| | Inverter output (P) % of S_{rated} | 0% | 100% | 100% | 20% |
| Australia C | Voltage | 207 | 215 | 253 | 260 |
| | Inverter output (P) % of S_{rated} | 20% | 100% | 100% | 20% |

Default volt-var settings for different regions are shown in the following table:

| Region | Default value | V_{V1} | V_{V2} | V_{V3} | V_{V4} |
|-------------|---|---------------|----------|----------|-------------|
| Australia A | Voltage | 207 | 220 | 240 | 258 |
| | Inverter reactive output (Q) % of S_{rated} | 44% supplying | 0% | 0% | 60% sinking |
| Australia B | Voltage | 205 | 220 | 235 | 255 |
| | Inverter reactive output (Q) % of S_{rated} | 30% supplying | 0% | 0% | 40% sinking |
| Australia C | Voltage | 215 | 230 | 240 | 255 |
| | Inverter reactive output (Q) % of S_{rated} | 44% supplying | 0% | 0% | 60% sinking |

5. On-Off Control

Inverter on-off local control.

6. Set Energy

Set the total power generation. You can modify the total power generation through this option.

7. Set address

Set the address (when you need to monitor multiple inverters simultaneously) , Default 01.

8. Set Input mode

SOFAR 7K~10.5KTLM-G3 has three MPPT channels, which can run independently or in parallel. Users choose the operation mode of MPPT according to the system design. Parallel mode is applicable to the case where one or two MPPT channels are in parallel., independent mode is applicable to the case where three MPPT channels run independently, and the default mode is independent mode.

9. Set Language

Set the inverter display language.

10. Set Anti Reflux

Enable or disable the anti-reflux function of the inverter, and set the reflux power. This function need to be used with external CT, please refer to this manual 4.4.3 CT for details.

| | | | | | |
|---------|-------------------|---------|-----------------|-----------------|--|
| “Enter” | 1 Enter setting | “OK” | 1 Set Time | | |
| | 2 Event List | | 2 Clean Energy | | |
| “Up”↑ | 3 System Info | “Up”↑ | 3 Clean Events | | |
| | 4 Display Time | | | | |
| “Down”↓ | 5 Software Update | “Down”↓ | 10 Set Reflux P | | |
| | | | “OK” | Input password! | |

| | | | | | |
|------|------|------------|------|------|--------------------------|
| “OK” | **** | Input 0001 | 0001 | “OK” | Anti Reflux Control |
| | | | | | Hard Anti Reflux Control |

| | | | | | |
|---------------------|------|--------|------|--------|----------------------------------|
| Anti Reflux Control | “OK” | Enable | “OK” | *.**KW | Input the allowable export power |
|---------------------|------|--------|------|--------|----------------------------------|

| | | | | | |
|-----------------------------|------|---------|------|--------|----------------------------------|
| Hard Anti Reflux Control | “OK” | Disable | “OK” | | Input the allowable export power |
| | | Enable | | *,**KW | |
| | | Disable | | | |

Press “Up” or “Down” to change the value of the first digit. Press “OK” to switch to second digit.

Press “Up” or “Down” to change the value of the second digit. After inputting all digit press “OK” to confirm.

11. Logic Interface

Enable or disable logical interfaces. Please refer to this manual 4.4.1 Logic interface for details.

12. IV Curve Scan

Shadow scanning, when the component is blocked or abnormal, causing multiple power peaks, by enabling this function, the peak point of maximum power can be tracked.

13. PCC select

Choose the method to detect PCC on-grid point power/current.

14. Autotest Fast

| | | | |
|------------------|----|------------------|----------------------------|
| 14.Autotest Fast | OK | Start Autotest | Long press the“√” to start |
| | | Testing 59.S1... | |
| | | ↓ | Wait |
| | | Test 59.S1 OK! | |
| | | ↓ | Wait |
| | | Testing 59.S2... | |
| | | ↓ | Wait |
| | | Test 59.S2 OK! | |
| | | ↓ | Wait |
| | | Testing 27.S1... | |
| | | ↓ | Wait |
| | | Test 27.S1 OK! | |
| | | ↓ | Wait |
| | | Testing 27.S2... | |
| | | ↓ | Wait |
| | | Test 27.S2 OK! | |
| | | ↓ | Wait |
| | | Testing 81>S1... | |
| | | ↓ | Wait |
| | | Test 81>S1 OK! | |
| | | ↓ | Wait |

| | |
|----------------------------------|--------------------|
| Testing 81>S2... | |
| ↓ | Wait |
| Test 81>S2 OK! | |
| ↓ | Wait |
| Testing 81<S1... | |
| ↓ | Wait |
| Test 81<S1 OK! | |
| ↓ | Wait |
| Testing 81<S2... | |
| ↓ | Wait |
| Test 81<S2 OK! | |
| ↓ | Long press the“√” |
| Auto Test OK! | |
| ↓ | Short press the“√” |
| 59.S1 threshold 253V 900ms | |
| ↓ | Short press the“√” |
| 59.S1: 228V 902ms | |
| ↓ | Short press the“√” |
| 59.S2 threshold 264.5V 200ms | |
| ↓ | Short press the“√” |
| 59.S2: 229V 204ms | |
| ↓ | Short press the“√” |
| 27.S1 threshold 195.5V 1500ms | |
| ↓ | Short press the“√” |
| 27.S1: 228V 1508ms | |
| ↓ | Short press the“√” |
| 27.S2 threshold 34.5V 200ms | |
| ↓ | Short press the“√” |
| 27.S2: 227V 205ms | |
| ↓ | Short press the“√” |
| 81>.S1 threshold 50.5Hz 100ms | |
| ↓ | Short press the“√” |
| 81>.S1 49.9Hz 103ms | |
| ↓ | Short press the“√” |
| 81>.S2 threshold 51.5Hz 100ms | |
| ↓ | Short press the“√” |
| 81>.S2 49.9Hz 107ms | |
| ↓ | Short press the“√” |
| 81<.S1 threshold 49.5Hz | |

| | |
|----------------------------------|--------------------|
| 100ms | |
| ↓ | Short press the“√” |
| 81<.S1 50.0Hz 105ms | |
| ↓ | Short press the“√” |
| 81<.S2 threshold 47.5Hz 100ms | |
| ↓ | Short press the“√” |
| 81<.S2 50.1Hz 107ms | |

15. Autotest STD

15.Autotest STD Long press the “√”

The test procedure is same as Autotest Fast, but it’s much more time consuming.

(B) “Event List” Interface as below:

Event List is used to display the real-time event records, including the total number of events and each specific ID No. and happening time. User can enter Event List interface through main interface to check details of real-time event records, Event will be listed by the happening time, and recent events will be listed in the front. Please refer to below picture. Long press the “√” enter into main menu interface, and short press the “√” to turn the page in standard interface, then enter into “2.Event List” interface.

| 2. Event List | |
|-------------------|--|
| 1. Current Events | 2. History Events |
| Fault information | 001 ID04 06150825 (Display the event sequence number, event ID number, and event occurrence time) |

(C) “SystemInfo” Interface as below

| 3.SystemInfo | -----Long press the “√” | |
|------------------|-------------------------|--|
| 1.Inverter Type | 10.Remote State | |
| 2.Serial Number | 11.Reflux Enable | |
| 3.GeneralSoftVer | 12.Reflux Power | |
| 4.HardVersion | 13.DRM0 | |
| 5.Country | 14.DRMn | |
| 6.SafetySwVer | 15.MPPT Scan | |
| 7.SafetyHardVer | 16.ForceControl | |
| 8.Modbus Address | 17.PCC Select | |

9.Input mode

Access the main menu by long pressing the “V” button, then long press the “V” button to enter “3. SystemInfo”. Turning the page down can select the system information to view.

(D) system Time

Long press the “V” button and short press the button to turn the page in the standard user interface to enter into “4.Display Time”,then long press the “V” button to display the current system time.

(E) Software Update

Users can update the software by USB flashdrive, SOFARSOLAR may provide an updated software to the user if it is necessary, The user needs to decompress the upgrade file to the an empty USB flash drive in a specific folder for it to update properly. *NOTE* After decompressing the file, a folder named “firmware” will appear in the USB flash drive.

6.4. Update Software online

SOFAR 7K~10.5KTLM-G3 inverters offer software upgrade via USB flash drive to maximize inverter performance and avoid inverter operation error caused by software bugs.

Step 1 Insert the USB flash drive into the compute.

Step 2 SOFARSOLAR will send the Software code to the user who needs to update. After user receive the file,please decompress file and cover the original file in USB flash drive.

Step 3 Insert the USB flash drive into the USB/WiFi interface.

Step 4

5.Software Update

Input password

Input 0715

Start Update

Updating DSP1...

Updating DSP2...

Updating ARM...

Step 5 If the following errors occur, please upgrade again. If this continues many times, contact technical support for help.

| | | |
|-----------------|------------------|------------------|
| USB Fault | MDSP File Error | SDSP File Error |
| ARM File Error | Update DSP1 Fail | Update DSP2 Fail |
| Update ARM Fail | | |

Step 6 After the update is completed, turn off the DC breaker, wait for the LCD screen to extinguish, then restore the WiFi connection and then turn on the DC breaker and AC breaker again, the inverter will enter the running state. User can check the current software version in SystemInfo>>>SoftVersion.

7. *Trouble shooting*

Outlines of this chapter

This topic describes how to perform daily maintenance and troubleshooting to ensure long term proper operation of the inverter.

7.1. Trouble shooting

This section contains information and procedures for solving possible problems with the inverter.

➤ This section help users to identify the inverter fault. Please read the following procedures carefully:

✧ Check the warning, fault messages or fault codes shown on the inverter screen, record all the fault information.

✧ If there is no fault information shown on the screen, check whether the following requirements are met:

- Is the inverter mounted in a clean, dry place with good ventilation?
- Is the DC switch turned ON?
- Are the cables adequately sized and short enough?
- Are the input and output connections and wiring in good condition?
- Are the configuration settings correct for the particular installation?
- Are the display panel and the communication cables properly connected and undamaged?

Follow the steps below to view recorded problems: Long press the button to enter the main menu from the standard interface. Select “ 2. Event List ” then long press the button to enter event list.

➤ Earth Fault Alarm

This inverter complies with AS/NZS 5033 for earth fault alarm monitoring.

If an Earth Fault Alarm occurs, the fault will be displayed on the LCD screen,

the red light will be on, and the fault can be found in the history of the fault. For the machine installed with Wi-Fi/GPRS, the alarm information can be seen on the corresponding monitoring website, and can also be received by the APP on the mobile phone.

Table 7-1 Event list

| Code | Name | Description | Solution |
|-------|-------------------------|--|--|
| ID001 | Grid OVP | The grid voltage is too high | If the alarm occurs occasionally, the possible cause is that the electric grid is abnormal occasionally. Inverter will automatically return to normal operating status when the electric grid's back to normal. |
| ID002 | Grid UVP | The grid voltage is too low | |
| ID003 | Grid OFP | The grid frequency is too high | |
| ID004 | Grid UFP | The grid frequency is too low | If the alarm occurs frequently, check whether the grid voltage/frequency is within the acceptable range. If yes, please check the AC circuit breaker and AC wiring of the inverter. If the grid voltage/frequency is NOT within the acceptable range and AC wiring is correct, but the alarm occurs repeatedly, contact technical support to change the grid over-voltage, under-voltage, over-frequency, under-frequency protection points after obtaining approval from the local electrical grid operator. |
| ID005 | GFCI | Charge Leakage Fault | Check for inverter and wiring. |
| ID006 | OVRT fault | OVRT function is faulty | If the alarm occurs occasionally, the possible cause is that the electric grid is abnormal occasionally. Inverter will automatically return to normal operating status when the electric grid's back to normal. |
| ID007 | LVRT fault | LVRT function is faulty | |
| ID008 | Island Fault | Island protection error | |
| ID017 | HwADFaultIGrid | Power grid current sampling error | If the grid voltage/frequency is NOT within the acceptable range and AC wiring is correct, but the alarm occurs repeatedly, contact technical support to change the grid over-voltage, under-voltage, over-frequency, under-frequency protection points after obtaining approval from the |
| ID018 | HwADFaultDCI | Wrong sampling of dc component of grid current | |
| ID020 | HwADFaultVGri d(AC) | Power grid voltage sampling error (AC) | |
| ID022 | GFCIDeviceFault (AC) | Leakage current sampling error(AC) | |

| | | | |
|-------|---------------------------|---|---|
| ID029 | ConsistentFault_ GFCI | Leakage current consistency error | local electrical grid operator. |
| ID030 | ConsistentFault_ Vgrid | Grid voltage consistency error | |
| ID031 | ConsistentDCI | DCI consistency error | |
| ID034 | SpiCommFault(A C) | SPI communication error (AC) | |
| ID035 | SChip_Fault | Chip error (DC) | |
| ID038 | InvSoftStartFail | Inverter failed to output | |
| ID041 | Relay Fail | Relay detection failure | |
| ID042 | Iso Fault | Low insulation impedance | Check the insulation resistance between the photovoltaic array and ground (ground), if there is a short circuit, the fault should be repaired in time. |
| ID043 | PEConnectFault | Ground fault | Check ac output PE wire for grounding. |
| ID044 | ConfigError | Error setting input mode | Check the input mode (parallel/independent mode) Settings for the inverter. If not, change the input mode. |
| ID048 | SNTypeFault | Serial number fault | Internal faults of inverter, switch OFF inverter, wait for 5 minutes, then switch ON inverter. Check whether the problem is solved. If no, please contact technical support. |
| ID050 | TempFault_Heat Sink1 | Radiator 1 temperature protection | |
| ID069 | PVOVP | PV over-voltage | Check whether the PV series voltage (Voc) is higher than the maximum input voltage of the inverter. If so, adjust the number of PV modules in series and reduce the PV series voltage to fit the input voltage range of the inverter. After correction, the inverter will automatically return to its normal state. |
| ID072 | SwBusRmsOVP | Inverter bus voltage RMS software overvoltage | |
| ID073 | SwBusInstantOV P | Inverter bus voltage instantaneous value software overvoltage | |
| ID082 | DciOCP | Dci overcurrent protection | |
| ID083 | SwOCPInstant | Output instantaneous current protection | |
| ID085 | SwAcRmsOCP | Output effective value current protection | |
| ID086 | SwPvOCPInstant | PV overcurrent software protection | |
| ID098 | HwBusOVP | Inverter bus hardware | |

| | | | |
|-------|-----------------------|--|---|
| | | overvoltage | |
| ID102 | HwPVOCP | PV hardware overflows | |
| ID103 | HwACOCP | Ac output hardware overflows | |
| ID105 | MeterCommFault | Meters communication fault | Check whether the meters wiring is correct. |
| ID110 | Overload1 | Overload protection 1 | Please check whether the inverter is operating under overload. |
| ID113 | OverTempDerating | Internal temperature is too high. | Make sure the inverter is installed where there is no direct sunlight. Please ensure that the inverter is installed in a cool/well ventilated place. Ensure the inverter is installed vertically and the ambient temperature is below the inverter temperature limit. |
| ID114 | FreqDerating | AC frequency is too high | Please make sure the grid frequency and voltage is within the acceptable range. |
| ID129 | unrecoverHwAcOCP | Output hardware overcurrent permanent failure | Internal faults of inverter, switch OFF inverter, wait for 5 minutes, then switch ON inverter. Check whether the problem is solved. If no, please contact technical support. |
| ID130 | unrecoverBusOVP | Permanent Bus overvoltage failure | |
| ID134 | unrecoverAcOCPInstant | Output transient overcurrent permanent failure | |
| ID142 | PermSpdFail(DC) | PV surge protection | |
| ID145 | USBFault | USB fault | Check the USB port of the inverter |
| ID146 | WifiFault | Wifi fault | Check the Wifi port of the inverter |
| ID147 | BluetoothFault | Bluetooth fault | Check the bluetooth connection of the inverter |
| ID152 | SafetyVerFault | The software version is inconsistent with the safety version | Contact for technical support and software upgrades. |
| ID154 | SciCommLose(ACC) | SCI communication error (AC) | |
| ID156 | SoftVerError | Inconsistent software versions | |

7.2. Maintenance

Inverters generally do not need any daily or routine maintenance. Heat sink should not be blocked by dust, dirt, debris or any other items. Before the

cleaning, make sure that the DC SWITCH is turned OFF and the circuit breaker between inverter and electrical grid is turned OFF. Wait at least for 5 minutes before cleaning.

✧ **Inverter cleaning**

Please clean the inverter with an air blower, a dry & soft cloth or a soft bristle brush. Do NOT clean the inverter with water, corrosive chemicals, detergent, etc.

✧ **Heat sink cleaning**

For the long-term proper operation of inverters, ensure there is enough space around the heat sink for ventilation, check the heat sink for blockage (dust, snow, etc.) and clean them if they exist. Please clean the heat sink with an air blower, a dry & soft cloth or a soft bristle brush. Do NOT clean the heat sink with water, corrosive chemicals, detergent, etc.

8. Technical data

8.1. Input parameters (DC)

| Technical Data | SOFAR 7KTLM- G3 | SOFAR 7.7KTL M-G3 | SOFAR 8KTLM- G3 | SOFAR 9KTLM- G3 | SOFAR 10KTL M-G3 | SOFAR 10.5KTL M-G3 |
|--|------------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|
| Recommended Max. PV input power | 10500Wp | 10500Wp | 12000Wp | 13500Wp | 15000Wp | 15000Wp |
| Max. DC power for single MPPT | 6250W/5 000W/50 00W | 6250W/5 000W/50 00W | 6250W/5 000W/50 00W | 6250W/5 000W/50 00W | 6250W/5 000W/50 00W | 6250W/5 000W/50 00W |
| Number of MPP trackers | 3 | | | | | |
| Number of DC inputs | 3 | | | | | |
| Max. input voltage | 600V | | | | | |
| Start-up voltage | 90V | | | | | |
| Rated input voltage | 360V | | | | | |
| MPPT operating voltage range | 80V~550V | | | | | |
| Full power MPPT voltage range | 200~500 V | 200~500 V | 230~500 V | 260~500 V | 280~500 V | 300~500 V |
| Max. input MPPT current | 20A/16A/16A | | | | | |
| Max. input short circuit current per MPPT | 30A/25A/25A | | | | | |
| Maximum inverter backfeed current to array | No backfeed current to array | | | | | |

8.2. Output parameters (AC)

| Technical Data | SOFAR 7KTLM- G3 | SOFAR 7.7KTL M-G3 | SOFAR 8KTLM -G3 | SOFAR 9KTLM -G3 | SOFAR 10KTL M-G3 | SOFAR 10.5KTL M-G3 |
|---------------------------------------|---|-------------------------|-----------------------|-----------------------|------------------------|--------------------------|
| Rated power | 7000VA | 7700VA | 8000VA | 9000VA | 10000VA | 10500VA |
| Max. AC power | 7700VA | 7700VA | 8800VA | 9900VA | 10000VA | 10500VA |
| Nominal output current | 31.8A | 35A | 36.4A | 40.9A | 45.5A | 45.6A |
| Max output current | 35A | 35A | 40A | 45A | 46A | 46A |
| Nominal grid voltage | L/N/PE, 220Vac, 230Vac, 240Vac | | | | | |
| Grid voltage range | 180Vac-276Vac (According to local standard) | | | | | |
| Nominal frequency | 50 / 60Hz | | | | | |
| Grid frequency range | 45Hz-55Hz/54Hz-66Hz (According to local standard) | | | | | |
| Active power adjustable range | 0~100% | | | | | |
| THDi | <3% | | | | | |
| Power factor | 1 default (adjustable+/-0.8) | | | | | |
| Power limit export | Zero export or adjustable power limit export | | | | | |
| Current (inrush) | 200A _{ac} , 1μs | | | | | |
| Maximum output fault current | 120A/20ms | | | | | |
| Maximum output overcurrent protection | 48A _{ac} | | | | | |
| Detection methods of isolated islands | Reactive Power Disturbance | | | | | |

8.3. Efficiency, Protection and Communication

| Technical Data | SOFAR 7KTL M-G3 | SOFAR 7.7KTL M-G3 | SOFAR 8KTL M-G3 | SOFAR 9KTL M-G3 | SOFAR 10KTL M-G3 | SOFAR 10.5KTL M-G3 |
|---------------------------------------|---|-------------------------|-----------------------|-----------------------|------------------------|--------------------------|
| Efficiency | | | | | | |
| Max efficiency | 98.1% | 98.1% | 98.1% | 98.1% | 98.1% | 98.1% |
| European weighted efficiency | 97.3% | 97.3% | 97.3% | 97.3% | 97.3% | 97.3% |
| Self-consumption at night | <1W | | | | | |
| Protection | | | | | | |
| DC reverse polarity protection | Yes | | | | | |
| AFCI protection | Optional | | | | | |
| Protection class/overvoltage category | I/ III for AC side,II for DC side. | | | | | |
| Safety protection | Anti-islanding, RCMU, Ground fault monitoring | | | | | |
| SPD | PV:Type II standard, AC:Type III standard | | | | | |
| Communication | | | | | | |
| Communication | RS485/USB/Bluetooth, Optional:WiFi/GPRS | | | | | |
| Operation data storage | 25 years | | | | | |

8.4. General Data

| Technical Data | SOFAR 7KTLM- G3 | SOFAR 7.7KTLM- G3 | SOFAR 8KTLM- G3 | SOFAR 9KTLM- G3 | SOFAR 10KTLM- G3 | SOFAR 10.5KTLM- -G3 |
|-----------------------------------|---|-------------------------|-----------------------|-----------------------|------------------------|---------------------------|
| General Data | | | | | | |
| Ambient temperature range | -30°C~+60°C | | | | | |
| Topology | Transformerless | | | | | |
| Degree of protection | IP65 | | | | | |
| Allowable relative humidity range | 0~100% | | | | | |
| Max. operating altitude | 4000m | | | | | |
| Noise | <25dB | | | | | |
| Weight | 17kg | | | 19 kg | | |
| Cooling | Natural | | | | | |
| Dimension | 468mm(W)×380mm(H)×187mm(D) | | | | | |
| Display | LCD & APP+Bluetooth | | | | | |
| Standard warranty | 10 years | | | | | |
| Over voltage category | DC side: overvoltage II AC side: overvoltage III | | | | | |
| Standard | | | | | | |
| EMC | EN 61000-6-1, EN 61000-6-2, ,EN 61000-6-3, EN 61000-6-4 | | | | | |
| Safety standards | IEC 62109-1/2, IEC 62116, IEC 61727, IEC 61683, IEC 60068 | | | | | |
| Grid standards | AS/NZS 4777.2020, G99, INMETRO | | | | | |

9. *Quality Assurance*

SOFARSOLAR *Factory's Warranty Terms and Conditions for Australia

Applicable products

These *Factory's Warranty Terms and Conditions (“Terms and Conditions”) only applies to the following products, which are distributed and installed in Australia.

Table

| Product | Standard warranty period (months) |
|-------------------------------------|-----------------------------------|
| Inverter | |
| GRID-TIED (SOFAR 7K~10.5KTLM-G3) | 120 |
| Accessories | |
| CT Clamp | 24 |
| smart Meter | 24 |
| WIFI dongle | 24 |

This factory warranty is a promise from SOFARSOLAR to its end users on the applicable products listed above.

Definitions

In these Terms and Conditions:

- “ACL” means Schedule 2 to the Competition and Consumer Act 2010 (Cth);
- “Claim” means any judgment, claim, demand, action, suit or proceeding for damages, debt, restitution, equitable compensation, account, injunctive relief, specific performance or any other remedy, whether by original claim, cross claim or otherwise whether arising at common law, in equity, under statute or

otherwise wherever arising, whether known or unknown at the time of these Terms and Conditions, whether presently in contemplation of the parties or not;

c) "Consequential Loss" means loss or damage, whether direct or indirect, in the nature of, among other things, loss of profits, loss of revenue, loss of production, liabilities in respect of third parties (whether contractual or not), loss of anticipated savings or business, pure economic loss, loss of opportunity and any form of consequential, special, indirect, punitive or exemplary loss or damages, whether or not a party was advised of the possibility of such loss or damage;

d) "End User" means a person or entity whose order for the purchase of the Product is accepted by SOFARSOLAR;

e) "Loss" means, in relation to any person, any damage, loss, cost, expense or liability incurred by the person or arising from any Claim, action, proceedings or demand made against the person, however arising and whether present or future, fixed or ascertained, actual or contingent and includes Consequential loss;

f) "Product" means any applicable product or products distributed and installed by SOFARSOLAR to the End User as set out in the Table of these Terms and Conditions;

g) "Warranty Period" means the applicable warranty period of the relevant Product as stipulated in the Table of these Terms and Conditions.

Warranty Conditions

Our goods come with guarantees that cannot be excluded under the ACL. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure. Subject to any statutory rights which cannot be excluded (including the ACL) and the terms of any warranty stipulated in these Terms and Conditions, the End User acknowledges that:

a) prior to purchasing the Product, the End User conducted a thorough

examination of the Product;

- b) SOFARSOLAR made no warranty, condition, description, or representation in relation to the Product outside those contained in these Terms and Conditions;
- c) all warranties, conditions, guarantees, and terms in relation to the state, quality or fitness of the Product and of every other kind whether expressed or implied by use, statute or otherwise are excluded.

To the fullest extent that SOFARSOLAR is able to limit the remedies available under these Terms and Conditions, SOFARSOLAR expressly limits its liability for any breach of a condition or warranty implied by virtue of any applicable legislation (including the ACL) to the following remedies in the event SOFARSOLAR decides a Product to be faulty or otherwise defective during the Warranty Period (or otherwise):

- a) The repair of the Product by SOFARSOLAR whether on-site or off-site;
- b) The replacement of the Product;
- c) The payment of the costs of having the Product repaired.

The payment of the costs of replacing the Product or acquiring equivalent goods. If the Product needs to be replaced, the balance of the Factor's Warranty Period will be applied and transferred to the replacement Product and will continue until its expiry. In this event, the End User will not receive any new warranty card or be entitled to a further Warranty Period, and the replacement Product(s) will be registered by SOFARSOLAR.

Unless otherwise agreed in writing by the parties, the Factory warranty exclusively covers the cost of one (1) freight to the End User, labour and material necessary to regain a faultless functioning Product. The Factory warranty does not cover, without limitation, Consequential Loss, repair reimbursement costs, transport costs, travel costs, accommodation cost of SOFARSOLAR personnel as well as any costs of associated third party staff and personnel. Express delivery costs will not be covered.

In the event SOFARSOLAR, in its sole discretion, decides that any faulty or otherwise defective Product will be repaired on-site or otherwise replaced, in some service areas or business cases, to encourage the End User using the installer's facilities to receive a faultless and functioning product, SOFARSOLAR may, in its sole discretion, offer a rebate to the End User or local installer/electrician to cover the on-site service labour under the following conditions:

The rebate will be eligible ONLY to the party who has carried out on-site service for the purported faulty or otherwise defective Product;

The purported faulty or otherwise defective Product has been returned in the original replacement product packaging to SOFARSOLAR and deemed to have workmanship or material defects upon testing and inspection by SOFARSOLAR. If the purported faulty or otherwise defective Product is deemed free of faults and defects that would qualify a replacement under these Terms and Conditions, then SOFARSOLAR is entitled to charge a retail price of the Product(s), shipping and packaging and any associated labour cost in replacing the purported faulty or otherwise defective Product;

SOFARSOLAR must be contacted prior to the site visit for authorisation. If the site is not located in a metropolitan area in Australia or if the installer is unable to be on-site, the End User must engage their own electrician to carry out and complete the on-site service;

The service rebate must be claimed strictly within two (2) months of the date upon which the on-site service is authorised by SOFARSOLAR.

SOFARSOLAR retains the right to arrange the warranty service for the End User and to use third parties for performing any warranty services.

SOFARSOLAR retains full title and ownership of the supplied replacement Product(s) until the purported faulty or otherwise defective Product has been received in accordance with these terms and conditions.

The End User may contact the dealer (SOFARSOLAR authorised dealer or distributor) or installer if the Product is faulty or otherwise defective.

All other purported costs including, but not limited to, compensation from any direct or indirect Loss arising from the faulty or otherwise defective Product or other facilities of the PV system, or loss of electrical power generated during the product downtime are NOT covered by the SOFARSOLAR limited warranty.

Scope of the Warranty

The warranty stipulated in these Terms and Conditions will not apply if SOFARSOLAR, in its sole discretion, decides that any one (1) of the following occurs:

The End user is in default under the General Terms and Conditions of other agreement governing the purchase of the Product, or

Any damage or defect to the Product is caused any one (1) or more of the following situations (the Dealers or Distributors are responsible and authorized by SOFARSOLAR for the following investigation):

Disassembly, attempted repair or modifications performed by any person not authorised by SOFARSOLAR in writing, or serial number or seals have been removed. Product modifications, design changes or part replacements without prior written approval of SOFARSOLAR;

The End user or installer has failed, refused or otherwise neglected to comply with the applicable safety regulations (IE, VDE standards or equivalent) governing the proper use of the Product in force from time to time;

The Product has been improperly stored and damaged by the dealer, distributor or the End User;

The fault or otherwise defect is damage sustained during transportation

(including painting scratch caused by movement inside packaging during shipping). A Claim for such transport damage should be made directly to the shipping company/insurance company as soon as the container/package is unloaded and such damage is identified;

The Product has been used and installed by an unauthorised or unlicensed installer who fails, refuses, or otherwise neglects to strictly follow any applicable user manual, installation guide and maintenance regulations supplied with the Product, including not ensuring sufficient ventilation for the Product as described in SOFARSOLAR installation guide;

Defects, faults, cosmetics or rendered non-functional damage caused by unforeseen circumstances, or force majeure event including, but not limited to, any vandalism, violent or stormy weather, lightning, flooding, power fluctuation, overvoltage, grid power surge, pests, fire damage, wind damage, or exposure to erosion, sea coasts/saltwater or other aggressive atmospheres or environmental conditions;

Use of the Product in combination with any unauthorised products, equipment or materials as per the user manual, installation guide and maintenance regulations supplied with the Product;

Combining the Product with any lead acid battery pack or any other lithium battery pack that is not listed on any SOFARSOLAR's battery compatibility list from time to time.

Limitation of Liability

a) This limited warranty supersedes and otherwise replaces any different SOFARSOLAR warranties and liabilities, whether oral, in writing, (non-obligatory) statutory, contractual, in tort or otherwise, consisting of, without quardary, and where permitted by using relevant law, any implied conditions, warranties or different phrases as regards exemplary quality or fitness for purpose. However, this limited warranty shall neither exclude nor limit any of your legal (statutory) rights provided under the relevant national

laws and regulations.

b) Subject to clauses 4(c) and (d):

i. all warranties, descriptions, representations, guarantees or conditions, whether express or implied by law, trade, custom or otherwise, and all specific conditions, even though such conditions may be known to SOFARSOLAR, are, to the fullest extent, expressly excluded;

ii. SOFARSOLAR is not liable for any delay or Loss arising from the supply of or failure to supply the Product or comply with an order of the End User whether due to shortfall, defect, incorrect delivery or otherwise for any reason whatsoever including breach of contract (including fundamental breach), negligence, breach of duty as bailee, or the wilful act or default of SOFARSOLAR.

c) These Terms and Conditions shall not exclude or limit the application of any provisions of any statute including any implied condition or warranty the exclusion of which would contravene any statute (including the ACL) or cause any part of this clause 4 to be illegal, invalid, void or unenforceable.

d) If the exclusion of liability in clause 4(b) is reduced, void or not available, SOFARSOLAR's liability for any Claims arising out of these Terms and Conditions, including liability for breach of these Terms and Conditions, in negligence or in tort or for any other common law or statutory action, shall:

i. be limited to the extent the Loss the subject of the Claim was caused directly by SOFARSOLAR; and

ii. in all events, exclude Loss relating to any delay in supply of the Product and for any Consequential Loss.

e) SOFARSOLAR guarantees the performance of the Product under the normal working conditions within the standard warranty term and provide limited technical support if applicable. However, SOFARSOLAR shall assume no liability for system malfunctions and any incurred loss or damages whatsoever.

Please refer to SOFARSOLAR Energy Storage Warranty Terms and Conditions for further information on SOFARSOLAR Energy Storage products.

Procedure for Claiming a Warranty

In the case of a faulty or otherwise defective Product please report that Product within the agreed warranty period, with a detailed error description to SOFARSOLAR's service hotline for registering and send the claim to SOFARSOLAR service department by fax/email or through SOFARSOLAR Warranty Claim Website at <https://service.sofarsolar.com/warranty/search> to process the warranty claim. The End User may also contact the dealer (SOFARSOLAR authorised dealer or distributor) or installer if the Product is defective or faulty.

To make a claim under the warranty, the End User must provide the following information and documentation of the faulty or otherwise defective Product:

1. Product Model and serial number
2. A copy of the valid purchasing invoice
3. Fault descriptions and error IDs (where applicable)
4. End user and/or claimant details
5. Detailed information about the entire system (module, PV system diagram, installation date, etc.)

6. Documentation of previous claims/exchanges (if applicable)

The warranty may not be guaranteed if the above information is not provided.

Extension of the Warranty Period

For SOFARSOLAR inverters, the End User may apply for a Warranty Period extension within 24 months for grid-tied inverter <50kW and 12 months for grid-tied ≥ 50 kW and energy storage inverter(hybrid) inverters from the date of production from SOFARSOLAR by providing the serial number and copy of the warranty card of the Product. SOFARSOLAR may reject any application received which does not meet the date requirement. An extended Warranty Period can be purchased to 10, 15, or 20 years. Please refer to the Warranty Extension Order Form for more information.

Once the purchase of the Warranty Period extension has been processed, SOFARSOLAR will send a Warranty Period extension certificate to the End User confirming the extended Warranty Period.

Any faults or defects that occur after the expiry of the Warranty Period, or which occur within the Warranty Period but which are listed in the warranty exceptions above, are deemed to be out-of-warranty cases. For all out-of-warranty cases, SOFARSOLAR, in its sole discretion, may charge fees to the End User including, without limitation:

- a) On-site service fee: cost of travel and time for the technician to deliver on-site service and labour cost for the technician, who is repairing, performing maintenance on, installing (hardware or software) and debugging the faulty product.
- b) Parts/materials fee: cost of replacement parts/materials (including any shipping/admin fee that may apply).

c) Logistics fee: cost of delivery and any other expenses incurred when defective products are sent from the user to SOFARSOLAR or/and repaired products are sent from SOFARSOLAR to the user.

Latest information about the warranty terms and conditions and local service hotline can be obtained from our website: www.sofarsolar.com.au

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact us

You can directly contact our professional after-sales team:

Sofarsolar Ausco Pty Ltd.

Tel: +61 401 734 463 / 408 500 386

Shenzhen Sofarsolar Co. Ltd.



Product Name: PV Grid-Connected Inverter

Company Name: Shenzhen SOFARSOLAR Co., Ltd.

ADD: 401, Building 4, AnTongDa Industrial Park, District 68, XingDong Community,
XinAn Street, BaoAn District, Shenzhen, Guangdong, P.R. China

Email: service@sofarsolar.com

Tel: 0510-6690 2300

Web: www.sofarsolar.com